

# Syringe to Syringe Transfer of Medication

1. Wash hands and prepare clean work surface.
2. Remove cap on end of medication syringe and attach the transfer device taking care not to contaminate either device.
3. Attach an empty BD syringe to the other end of transfer device and push medication syringe into empty syringe.
4. If there is more than one syringe of medication remove the empty syringe and attach second medication syringe and push to transfer medication.
5. Once all medication is in syringe, remove transfer device and empty syringe taking care not to contaminate the end of the syringe with the medication.

